

Work Order ID 76830

76830

Page 1

November-21-11 3:36:06 PM

Item ID: D350-567-117

Accept

N900040100

Setup Start *NS1*

Revision ID:

Item Name: Floor Window Installation, Extra Large

Stop *NS2*

Start Date: 21/11/2011 Start Qty: 1.00

1

Cust Item ID:

Required Date: 30/11/2011 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: MLJ Date: 11/11/21 Tooling: _____ Date: _____

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Run Start *NR1*

Stop *NR2*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
Draw Nbr	Revision Nbr								
IIN-D350-567	Rev D								
100		0.00							
100	DOCUMENT CONTROL								
DC	Memo	0.00							
Document Control	Photocopy bluefile and type labels as per PPP D350-567-117 CHG002								
110		0.00							
110	Packaging								
Packaging	Memo	0.00							
Packaging	Pick Packing Kit								
	ENSURE DT 8439 TEMPLATE IS INCLUDED								
120		0.00							
120	QC4- 100% Inspect kits for completeness								
QC	Memo	0.00							
Quality Control									

8/11/17/08

MLJ 11-12-6

11/12/15

8/11/12/02

QC

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 76830***76830***

Page 2

November-21-11 3:36:06 PM

Item ID: D350-567-117

Accept

N900040100Setup Start ***NS1***

Revision ID:

Item Name: Floor Window Installation, Extra Large

Stop ***NS2***

Start Date: 21/11/2011 Start Qty: 1.00

1

Cust Item ID:

Required Date: 30/11/2011 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: _____ Date: _____ Tooling: _____ Date: _____

Run Start ***NR1***

QC: _____ Date: _____ SPC (Y/N): _____ Date: _____

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130	Packaging	0.00							
130									
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPP D350-567-117 Location: _____								
140	QC21- Final Inspection - Work Order Release	0.00							
140									
QC	Memo	0.00							
Quality Control									

REV B

11/12/08

MR 11-12-08

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

November 21-11 3:36:11 PM

Page 1

Work Order ID: 76830

76830

Parent Item: D350-567-117

D350-567-117

Parent Item Name: Floor Window Installation, Extra Large

Start Date: 21/11/2011

Required Date: 30/11/2011

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP Rev:A 08.09.30 new issue EC verified by: DD

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D350-567-031

CH 67001

Manufactured

No

110

Each

1.0000

1

**

376832

2

D350-567-031

Interior Floor Window (Sliding Door Compatible)

Location

Loc Qty

Loc Code

FG023

1

74017

1

D350-567-113

CH 67003

Manufactured

No

110

Each

0.0000

1

**

376831

2

D350-567-113

Replacement Window, Extra Large

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

5.0 PARTS LIST

Qty -015	Qty -017	Qty -025	Qty -027	Qty -111	Qty -117	Part Number	Description
X						D350-567-015	FLOOR WINDOW INSTALLATION (SMALL)
	X					D350-567-017	FLOOR WINDOW INSTALLATION (SMALL)
		X				D350-567-025	FLOOR WINDOW INSTALLATION (LARGE)
			X			D350-567-027	FLOOR WINDOW INSTALLATION (LARGE)
				X		D350-567-111	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
					X	D350-567-117	FLOOR WINDOW INSTALLATION (EXTRA LARGE)
1	1					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
		1	1			D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
				1	1	D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
	1		1	1		D350-567-115	INTERIOR FLOOR WINDOW KIT
1		1			1	D350-567-031	INTERIOR FLOOR WINDOW KIT (SLIDING DOOR COMPATABLE)

Qty -013	Qty -023	Qty -113	Qty -115	Qty -031	Part Number	Description
X					D350-567-013	REPLACEMENT WINDOW KIT (SMALL)
	X				D350-567-023	REPLACEMENT WINDOW KIT (LARGE)
		X			D350-567-113	REPLACEMENT WINDOW KIT (EXTRA LARGE)
			X		D350-567-115	INTERIOR FLOOR WINDOW KIT
				X	D350-567-031	INTERIOR FLOOR WINDOW KIT (SLIDING DOOR COMPATABLE)
1					D2125	REPLACEMENT WINDOW, SMALL
	1				D2942	REPLACEMENT WINDOW, LARGE
		1			D3290-041	REPLACEMENT WINDOW ASSEMBLY, EXTRA LARGE
1					D2126-0600	SEAL
	1				D2463-0750	NEOPRENE SEAL
		1			D2463-0860	NEOPRENE SEAL
	9	12			2600-6	1/4 TURN FASTENER
	9	12			2600-LW	WASHER
	9	12			212-12	RECEPTACLE
	22	21			AN526C832R9	SCREW (OR AN526C832-9, OR MS51957-126)
	44	42			AN960JD8	WASHER
	22	21			MS21042L08	NUT (OR MS21042-08)
	18	24			MS20426AD3-5	RIVET
2 SQ. YD	2 SQ. YD	2 SQ. YD			N/A	9.7oz 7781 'S' GLASS UNIVERSAL WEAVE
				1	D2463-0450	NEOPRENE SEAL
				1	D3210-1	DOUBLER
				1	D3211-1	BRACKET
				1	D3212-1	FLOOR WINDOW
				1	D3213-041	DOOR ASSEMBLY
			1		D3293-1	DOUBLER
			1		D3294-1	BRACKET
			1		D3295-041	FLOOR WINDOW
			1		D3296-041	DOOR ASSEMBLY
			1		D2463-0530	NEOPRENE SEAL
			9	8	AN526C632R12	SCREW (OR AN526C632-12, OR MS51957-32)
			9	8	AN960JD6	WASHER
			9	8	MS21042L06	NUT (OR MS21042-06)
			2	40	MS20470AD4-5	RIVET
			115	90	MS20470AD4-6	RIVET
			15	20	MS20470AD4-7	RIVET

• COPYRIGHT © 2000 BY DART AEROSPACE LTD. •

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.

Revision: D

Date: 08.07.08